

Urnex Brands, Inc. Specialty Cleaning Products for Coffee and Espresso Equipment Since 1936



- 1. To fill measuring cup loosen cap and squeeze bottle. Mix solution of 15-30 ml Rinza® Milk Frother Cleaner per 500 ml cold water. Insert suction tube into solution.
- Run entire solution through frother.
- Repeat above with clean cold water to thoroughly rinse all components.
- Make and discard a cup of espresso to ensure no residue remains.

 $\textbf{TIP:} \ Soak \ parts \ or \ steam \ wand \ for \ 15-30 \ minutes \ in \ 30 \ ml \ Rinza \& \ Milk \ Frother \ Cleaner \ per \ 500 \ ml \ warm \ water. \ Rinse \ all \ components.$